### **EV-SERIES**



## **EV-SERIES**


Shown from left to right: EV-43M4, EV-11, EV-52H3, EV-23

#### **HYDRAULIC VALVES**

EAGLE PRO hydraulic valves are available for most of your applications. EAGLE PRO hydraulic valves are available with a manual control, solenoid directional control and flow control valves. EAGLE PRO hydraulic valves are designed and manufactured for safe operation up to 10,000 PSI.




EV-11



Needle valve, manually control the speed of cylinder, can be used as shut-off valve for temporary load holding.



EV-23



Manually Operated Check Valve. used to hold load with single or double acting cylinder, manually opened to allow oil to flow back to oil reserve when cylinder retracts



# **EV-SERIES**

## **EV-SERIES**

### **DIRECTIONAL CONTROL VALVES**

Used with cylinder	Valve Operation	Valve Location	Model	Valve Type	Valve Function	Hydraulic Symbol	Weight (lbs)
Single Acting	Manual	Pump Mounted	EV-42H2	2 Position	Advance Return	A P	4.4
	Manual	Pump Mounted	EV-43M3	3 Position	Advance Hold/Return	P T	2.86
	Manual	Remote Mounted	EV-43M3L	3 Position	Advance Hold/Return		4.84
	Manual	Pump Mounted	EV-43M3T	3 Position	Advance Hold/Return	A	8.36
	Manual	Remote Mounted	EV-43M3LT	3 Position	Advance Hold/Return		10.34
	Solenoid 24V	Pump Mounted	EV-52H2	2 Position	Advance Return	A P	3.96
	Solenoid 24V	Pump Mounted	EV-52H3	2 Position	Advance Return	A P T	3.96
Double Acting	Manual	Pump Mounted	EV-43M4	3 Position	Advance Hold/Return	A B P T	2.86
	Manual	Remote Mounted	EV-43M4L	3 Position	Advance Hold/Return		4.84
	Manual	Pump Mounted	EV-43M4T	3 Position	Advance Hold/Return	A B	8.36
	Manual	Remote Mounted	EV-43M4LT	3 Position	Advance Hold/Return	PT	10.34
	Solenoid 24V	Pump Mounted	EV-52H4	2 Position	Advance Return	A B P T	3.96